

9. After brew cycle has finished and tea no longer drips from the funnel tip, carefully remove the brew funnel and discard used tea bags. NEVER RE-USE TEA BAGS.

BREW IT RIGHT

Allow the brew cycle to finish before

- 2. If the water is not 195 Degrees ($\pm 10^{\circ}$ F):
 - The temperature probe and/or thermostat may not be functioning properly.
 - The temperature probe and boiler may be coated with lime scale from the hardness in the water.

- 2 Programming; skip to Calibrate Flow.
- Parts:
- 2L pitcher: CCP#116967
- 3L pitcher: CCP#122566

IS THE FUNNEL INTERIOR CLEAN? **IS THE STRAINER CLEAN?**



Never stack tea

bags on top of each other.

adding flavor sweetener pack for sweet tea.



- 2. Discard the tea bags from the brew basket immediately after the brew cycle is finished. NEVER RE-USE TEA BAGS.
- 3. For sweetened/flavored tea, follow these guidelines for each brewed amount:

1.5 GALLON: Empty entire contents of 1 (one) correct flavor/ sweetener pack into the 1.5 gallons of freshly brewed tea. **3 GALLON:** Empty entire contents of 2 (two) correct flavor/ sweetener packs into the 3 gallons of freshly brewed tea.

- 4. Wear a foodservice glove, and use a clean, stainless steel spoon (or whisk) sufficient in length to reach the bottom of the container holding the tea.
- 5. Mix extremely well, stirring enough times until all the sweetener/flavor is dissolved.
- 6. Immediately place the lid on the urn.
- 7. Discard product after 6 (six) hours.

Use the appropriate label to identify the flavor contained in each urn




3. Call 1-800-241-COKE (2653) for service.

SERVING TEMPERATURE

- 1. Never use a warm glass.
- 2. Always use correct Ice Fill.

Fill the cup with $\frac{3}{4}$ lce for the Best Drink!



FILL IT RIGHT! **Drink Quality Counts.**

The flow of brew water/tea through the funnel must not be slowed because of a clogged or dirty strainer. The interior of the funnel should not have any stains or residues that might add bitter notes to the tea. Replacement funnel tip & screen kit (pictured) is available from Coca-Cola Parts, #121048.



For more information, refer to the **ITCB Brew Volume Calibration** Instructions from BUNN, found on their website www.bunn.com.



Freshness

First in...First Out!

WHY IT'S IMPORTANT

Remember, great taste is why your customer orders iced tea. Your customers expect to experience great tasting, fresh brewed iced tea! Fresh tea bags are essential to producing quality brewed iced tea.

WHAT TO CHECK

Tea Bags produced by The Coca-Cola Company for your fresh brewed tea are packaged by the case. To make certain you always serve only fresh tea bags, pay attention to these conditions:



- 1. Check the date code on the case: Each case of tea bags is stamped with a date code indicating the "Enjoy By" date. The date code is on a label affixed to the box.
- 2. Rotate your tea bag stock. Always use the oldest tea bags first to maintain freshness. Remember FIFO...first in, first out.
- 3. Avoid using tea bags that are too old. Tea bags should be used before "Enjoy By" date. The shelf life for each product from the date of each manufacturer is 12 months.
- 4. Discard the tea bags from the brew basket immediately after the brew cycle is finished. NEVER RE-**USE TEA BAGS.**
- 5. The maximum hold time is 6 (six) hours. To help ensure the tea you serve is always fresh, a **brew date** sticker is available via the Coke Catalog for use with your dispenser urns. Place the sticker on the side of the urn and simply write in the date and time the tea was placed in the urn. Contact GOOD UNTIL: your Coca-Cola Sales Representative should

you want these stickers.

- 6. Store tea at room temperature away from items that could impact taste (e.g. onions).
- 7. Keep boxes closed when not in use to avoid moisture getting into the box which can cause mold.



Cleanliness

WHY IT'S IMPORTANT

Keeping your dispensing system clean helps keep it operating properly. A clean, sanitary appearance communicates quality to your customers.

WHAT TO DO

It's easy to keep your dispensing area clean and orderly when you follow this regular schedule of activities.



Your customers associate a clean, tidy area with quality.



1 Once a day, turn the faucet in a from the faucet body and disassemble all faucet parts.

6 Thoroughly clean the entire

inside surface of the dispenser

and the faucet shank using a small

brush (BOM #00674.0000) mild de-

tergent and water solution. Thor-

oughly rinse the dispenser with

clean water.



SLIMLINE URN DAILY CLEANING INSTRUCTIONS

2 Transfer these parts to a three sink is used for clean rinse, and the third sink with a sanitizer solution least 50-100 ppm).



7 Prepare a sanitizer solution in chlorine




8 Pour a small amount of sanitizer solution into the dispenser. Use a bristle brush (BOM #00674.0000) to clean all the way through the faucet shank. Repeat 3 times.



4 Allow the parts to soak in a

sanitizer solution for a minimum of

ten minutes.





5 Remove the faucet parts from

the sanitizer solution and rinse

thoroughly. Allow parts to air dry

over night.


10 Assemble the faucet components and attach the faucet to the dispenser turning clockwise


WEEKLY CLEANING



MONTHLY CLEANING

3 Use a bristle brush (BOM #00674.0000) to thoroughly scrub counterclockwise direction and compartment sink for cleaning. Fill remove the faucet from the disthe first sink with a soap solution the faucet body. penser. Unscrew the faucet cap using a mild detergent, the second















Remove the sprayhead daily.

BREWER

• Wash in hot water and dish detergent, rinse, sanitize, and air-dry.

1. Place the ON/OFF switch in the "OFF" position.

• Ensure sprayhead holes are not blocked • Wipe the sprayhead area of the brewer.

CLEANING INSTRUCTIONS

2. Wipe the exterior of the machine daily.

- 4. Thoroughly clean the brew basket after each use.
- The funnel tip and screen must be free of any tea particles or residue.
- Wash with dish detergent, rinse, sanitize, and air-dry.



1 Once a week, fill the dispenser with a chlorine solution (75°F warm chlorine solution of at least 50-100 ppm).



form the daily cleaning procedures on the faucet and dispenser.

2 Draw a small amount (2 oz.) of presoak through the faucet making contact with the faucet components. Allow the dispenser to soak over night. The next morning, per-



1 It is recommended the faucet seat cup be replaced every 6 months. (B.O.M. #00600.0000)



2 Discard the old seat cup. The faucet assembly (B.O.M.#03260.0001) can be ordered for replacement.

TROUBLESHOOTING

PROBLEM	PROBABLE CAUSE	REMEDY
Brew cycle will not start	No water or no power	 Make sure the water lines and valves are open Make sure the brewer is plugged in, or check the circuit breaker Make sure the ON/OFF switch is working Could be front enable/on-off switch
Weak or bitter tasting beverage	Missing sprayhead or brew funnel tip	Replace sprayhead or brew funnel
	Dirty sprayhead or brew basket	 Clean and sanitize the sprayhead and brew basket
	*Dirty dispenser faucet	*If dirty dispenser faucet: disassemble, clean and sanitize the dispenser faucet

